



CHOOSING QUALITY IS ALWAYS THE BEST DECISION, AND THERE SHOULD BE NO EXCEPTIONS. THAT'S WHY WHEN LOOKING FOR AN ELITE, COMPREHENSIVE EXTENDED WARRANTY PROGRAM THE ONLY RIGHT CHOICE IS TOTAL PROTECTION PLAN.

Extended Service Agreement Program



Extended warranties provide peace of mind and assure that things go smoothly during a mechanical breakdown. That's why it's important to purchase a quality program like Total Protection Plan. With comprehensive coverages at a value price, Total Protection Plan is the right choice for everyone who wants to prepare for future problems.

Total Protection Plan is there the moment your vehicle breaks down, by providing benefits such as towing, roadside assistance and rental. Once at the repair facility, Total Protection Plan really goes to work by providing experienced professional claims adjusters who partner with your mechanic to ensure covered repairs are done effectively and in a timely manner. Finally, Total Protection Plan completes the claims process by paying the repair facility, minus any deductible or reimburses you directly. In all, Total Protection Plan makes a confusing, difficult situation less stressful and insures peace of mind wherever the road may take you.

Get total care and total value with Total Protection Plan.









NEW & PRE-OWNED SUPREME COVERAGE

Supreme coverage is the most comprehensive program offered. Supreme is suggested for those individuals who want maximum protection that covers all the major components on their vehicle. The only exclusions are items listed In the What Is Not Covered section of the contract, some of which include:

- · Glass, Lenses, Sealed Beams and Light Bulbs
- · Brake Rotors, Drums, Pads and Shoes
- Exhaust and Emission Systems
- · Spark Plugs, Wires, Cap and Rotor
- · Battery, Shocks and Clutch Assembly
- · Safety Restraint Systems
- · Wipers, Hoses, Belts, and Fasteners
- · Trim, Moldings, Upholstery and Carpet
- Bumpers, Body Work, and Wheels



COVERAGE OPTIONS

Supreme - Our best and most comprehensive coverage, Supreme covers virtually every vehicle component. Everything listed to the right is included with Supreme, plus a whole lot more.

Deluxe - (includes Engine, Transmission, Transfer Case, Drive Axle, Cooling, Steering, Brakes, Electrical, Fuel Delivery, Air Conditioner, Suspension, and Enhanced Electrical)

Enhanced - (includes Engine, Transmission, Transfer Case, Drive Axle, Cooling, Steering, Brakes and Electrical)

Powertrain Plus - (includes Engine, Transmission, Transfer Case, Drive Axle, and Cooling)

Wrap (New Only) - This coverage "wraps" around the manufacturer's powertrain warranty giving you supreme coverage for the duration of the manufacturer's warranty. Wrap covers everything that is listed to the right, plus a whole lot more (minus the powertrain).

ANCILLARY BENEFITS

(Included with all coverage options)

No deductible will be charged for the following benefits. Daily limits apply.

Rental
Mechanical First Aid
Battery Service
Delivery Service
Towing Service
Locksmith Service
Tire Service
Trip Interruption

VEHICLE COVERED COMPONENTS

Engine: Cylinder Block, Cylinder Head(s) and All Internally-Lubricated Parts contained within the Engine including: Pistons; Piston Rings; Connecting Rod Bearings; Crankshaft; Crankshaft Main Bearings; Camshaft; Camshaft Bearings; Cam Followers; Timing Chain or Belt; Timing Gears, Guides, Tensioners; Rocker Arms; Rocker Shafts; Rocker Bushings; Cylinder Head Valves; Valve Guides; Valve Lifters; Valve Springs; Valve Seals; Valve Retainers; Valve Seats; Push Rods; Water Pump; Oil Pump and Oil Pump Housing; Harmonic Balancer; Oil Pan; Flywheel/Flex Plate, Timing Chain Cover; Intake and Exhaust Manifolds; Valve Covers; Engine Mounts; Seals and Gaskets.

Turbochargers/Superchargers: including Housing, Internal Parts, Seals and Gaskets.

Transmission: [Automatic or Standard] Transmission Case and all Internal Parts plus: Torque Converter, Vacuum Modulator; Electronic Shift Control Unit; Transmission Cooler; Transmission Mounts; Oil Pan; Seals and Gaskets.



Transfer Case: Transfer Case and All Internal Parts; Seals and Gaskets.

Drive Axle: (Front and Rear) Drive Axle Case; All Internal Parts contained within the Drive Axle; Locking Hubs, Drive Shafts; Universal Joints; Constant Velocity Joints; Axle Bearings; Four-Wheel Drive Actuator; Differential Cover; Seals and Gaskets.

Cooling: Engine Cooling Fan and Motor; Fan Clutch; Belt Tensioner, Radiator; Heater Core; Thermostat; Blower Motor; Hot Water Valve.

Steering: All Internal Parts contained within the Steering Box; Rack and Pinion Gear; Power Steering Pump; Power Steering Hoses; Steering Knuckles; Pitman Arm; Idler Arm; Tie Rod Ends and Drag Link; Upper and Lower Steering Column Shafts and Couplings, including Internal Tilt-Wheel Mechanism; Steering Box and Rack and Pinion Gear Housings; Seals and Gaskets; Rear Wheel Steering: Rear Steering Shaft and Couplings; Power Cylinder and Pump; Electronic Control Unit/Solenoid; Phase Control Unit; Stepper Motor; Steering Box; Control Valve; Rack; Tie Rod Ends; Seals and Gaskets.

Brakes: Master Cylinder; Power Brake Cylinder; Vacuum Assist Booster; Hydro Boost; Disc Brake Caliper; Wheel Cylinders; Compensating Valve; Brake Hydraulic Lines and Fittings; Hydraulic Control Unit; Seals and Gaskets. The following ABS Parts are also covered: Electronic Control Processor; Wheel Speed Sensors; Hydraulic Pump/Motor Assembly; Pressure Modulator Valve/Isolation Dump Valve; Accumulator; Seals and Gaskets.




Electrical: Alternator; Voltage Regulator; Starter Motor; Starter Solenoid and Starter Drive; Engine Compartment Wiring Harness; Computerized Timing Control Unit; Electronic Ignition Module; Crank Angle Sensor; Knock Sensor; Ignition Switch; Ignition Switch Lock Cylinder; Front and Rear Window Wiper Motor, Washer Pump and Switch; Stop Lamp Switch; Headlamp Switch; Turn Signal Switch; Heater/A.C. Blower Speed Switch; Manual Heater/A.C. Control Assembly, and Horns.

Fuel Delivery: Fuel Pump; Fuel Injection Pump and Injectors; Vacuum Pump; Fuel Tank; Fuel Tank Sending Unit; Metal Fuel Delivery Lines.

Air Conditioner: Condenser; Compressor, Compressor Clutch and Pulley; Air Conditioning Lines and Hoses; Evaporator; Idler Pulley and Idler Pulley Bearing; High/Low Compressor Cutoff Switch; Expansion Valve; Pressure Cycling Switch; Seals and Gaskets. The following parts are also covered if they are required in connection with the repair of a covered part listed above: Accumulator/Receiver Dryer; Orifice Tube; Oil and Refrigerant.

Front and Rear Suspension: Upper and Lower Control Arms; Control Arm Shafts and Bearings or Bushings; Upper and Lower Ball Joints; Radius Arm and Bushings; Torsion Bars and Mounts or Bushings; Stabilizer Bar, Links and Bushings; Struts; Spindle and Spindle Support; Wheel Bearings; and Seals and Gaskets. Variable Dampening Suspension: Compressor; Control Module; Actuator; Solenoid; Height Sensor; Mode Selector Switch; Seals and Gaskets.



Enhanced Electrical: Automatic Climate Control Programmer; Electronic Instrument Cluster; Mileage Computer; Distributor; Ignition Coil; Electronic Combination Entry System (Does Not Include Transmitters and Receivers for Remote Locks); Cruise Control Module, Transducer, Servo and Amplifier; Powertrain Control Module; Headlamp Motors; Power Window Motor; Power Seat Motor; Power Mirror Motor; Power Antenna Motor/Mast Assembly; Convertible Top Motor, Power Sunroof Motor; Power Window Switch; Cruise Control Engagement Switch; Power Seat Switch; Power Mirror Motor Switch; Rear Defogger Switch; Power Door Lock Actuator and Switch

Contact your dealer to find out more about these great coverages.

Administered by: **Prizm Administrative Solutions, Inc.**P.O. Box 1088

Wheat Ridge, CO 80034-1088

Administration (800) 445-4065 • Claims (800) 809-2034

Note: This brochure is not a service agreement, but an outline of available coverage. Please see the service agreement for exact coverages, terms and conditions.